



The product is installed in these energy transmission lines:

TR60 continuous

INSTRUCTION
MANUALS





Please find the relevant reference guides on our instruction manuals page:

<https://www.giovenzana.com/leaflets/>

TR6008W

IN-LINE FEED



| | | |
|----------|------|--------|
| Material | body | nylon |
| Weight | | ~170 g |

Dimensions in mm / illustrations NOT in scale